

ECH-8-DM

CONTROLLER FOR WATER
HEATERS / COOLERS WITH
EC FAN

Mounting and operating instructions



Table of contents

SAFETY AND PRECAUTIONS	3
PRODUCT DESCRIPTION	4
ARTICLE CODES	4
INTENDED AREA OF USE	4
TECHNICAL DATA	4
STANDARDS	4
OPERATIONAL DIAGRAMS	5
WIRING AND CONNECTIONS	6
MOUNTING INSTRUCTIONS IN STEPS	6
OPERATING INSTRUCTIONS	8
VERIFICATION OF INSTALLATION	9
TRANSPORT AND STORAGE	10
WARRANTY AND RESTRICTIONS	10
MAINTENANCE	10

SAFETY AND PRECAUTIONS



Read all the information, the datasheet, Modbus map, mounting and operating instructions and study the wiring and connection diagram before working with the product. For personal and equipment safety, and for optimum product performance, make sure you entirely understand the contents before installing, using or maintaining this product.



For safety and licensing (CE) reasons, unauthorised conversion and /or modifications of the product are inadmissible.



The product should not be exposed to abnormal conditions, such as extreme temperatures, direct sunlight or vibrations. Long-term exposure to chemical vapours in high concentration can affect the product performance. Make sure the work environment is as dry as possible; avoid condensation.



All installations shall comply with local health and safety regulations and local electrical standards and approved codes. This product can only be installed by an engineer or a technician who has expert knowledge of the product and safety precautions.



Avoid contacts with energised electrical parts. Always disconnect the power supply before connecting, servicing or repairing the product.



Always verify that you apply appropriate power supply to the product and use appropriate wire size and characteristics. Make sure that all the screws and nuts are well tightened and fuses (if any) are fitted well.



Recycling of equipment and packaging should be taken into consideration and these should be disposed of in accordance with local and national legislation / regulations.



In case there are any questions that are not answered, please contact your technical support or consult a professional.

PRODUCT DESCRIPTION

The ECH series are controllers for water air coolers or hot water air heaters that are equipped with EC fans. Typically, they are used to cool or to heat warehouses and industrial areas. The temperature setpoint can be steplessly adjusted via the potentiometer. It has an unregulated output (ON-OFF) to control a water valve or electric heater. The EC fan speed can be manually selected via the rotary switch with 7 positions (Automatic, 5 manual steps and OFF). In Automatic mode, EC fan speed is regulated automatically based on the setpoint temperature. All settings can be adjusted via Modbus RTU communication. In remote mode, the controller can be overdriven by remote Master device.

ARTICLE CODES

Article code	Supply voltage
ECH-8-DM	85 – 305 VAC / 50 – 60 Hz

INTENDED AREA OF USE

- Warehouse air coolers equipped with EC fan and water valve
- The ideal controller for hot water air heaters in warehouses, sheds/stables, etc.
- Temperature controlled ventilation systems
- For indoor use, surface wall mounted

TECHNICAL DATA


- Supply voltage: 85 - 305 VAC / 50 – 60 Hz
- Stepless analogue output in automatic mode: 0 – 6 (0 – 10) VDC / max. load 200 Ω
- Unregulated output for valve / heater control: supply voltage (Us) / I_{max} 10 A
- Heating/cooling mode with jumper setting
- Analogue output with jumper (0-6 / 0- 10 VDC) or Modbus setting
- Input for PT500 temperature sensor
- Control switch with 7 positions: Off position + hand set position 1 to 5 + Auto mode
- Potentiometer for temperature setpoint (range: 5°C – 35°C)
- RGB LED for status indication
- Modbus RTU communication
- Plastic enclosure for wall fixing
- Protection class: IP54
- Operating ambient conditions:
 - ▶ Temperature: -10—50 °C
 - ▶ Rel. humidity: 5 – 90% rH, non-condensing

STANDARDS

- Low Voltage Directive 2014/35/EU
- Electromagnetic Compatibility (EMC) Directive 2014/30/EU
- RoHS Directive 2011/65/EU



OPERATIONAL DIAGRAMS




WIRING AND CONNECTIONS

L, N, PE	Supply voltage 85 – 305 VAC / 50 – 60 Hz
PE, N, L1	Unregulated output to control an external water valve or electric heater - I _{max} 10 A
TEMP	Optional temperature sensor PT500 (type FLTSN-P500-010 or similar)
Ao, Gnd	Analogue output to control EC fan speed (0 - 6 VDC or 0 - 10 VDC)
A, /B	Modbus RTU communication

MOUNTING INSTRUCTIONS IN STEPS

Before you start mounting the unit, read carefully **“Safety and Precautions”** and follow these steps:

1. Unscrew the front cover and open the enclosure.
2. Fix the unit onto the wall or panel using the provided screws and dowels. Mind the correct position and mounting dimensions as shown in **Fig. 1** and **Fig. 2**.




3. Insert the cables through the cable glands and do the wiring according to the wiring diagram (see **Fig. 3**) while adhering to the information from section **“Wiring and connections”** above.

- 3.1 Connect the power supply cables to the terminals.
- 3.2 Connect the cables of the load (fans and valve/heater) to the terminals.
- 3.3 Connect the power earth cables to the dedicated places.
- 3.4 Install the temperature probe in such a way it measures the temperature in the air of the desired area.

Cables must be less than 4m.

Fig. 3 Wiring and connections



<p>1 - Terminal block</p>	
<p>2 - Analogue output range selection</p>	<p>Jumper removed (default) - 0-6 VDC Jumper installed - 0-10 VDC</p>
<p>3 - Temperature mode selection</p>	<p>Jumper removed (default) - heating Jumper installed - cooling</p>
<p>4 - PROG header</p>	<div style="display: flex; justify-content: space-between;"> <div style="text-align: center;"> <p>1 2 3 4 5</p> </div> <div style="text-align: center;"> <p>Put a jumper onto pins 1 and 2 and wait for at least 5 seconds to reset the Modbus communication parameters</p> </div> </div> <div style="display: flex; justify-content: space-between; margin-top: 10px;"> <div style="text-align: center;"> <p>1 2 3 4 5</p> </div> <div style="text-align: center;"> <p>Put a jumper onto pins 3 and 4 and restart the supply to enter bootloader mode</p> </div> </div>

4. Tighten the cable glands.

5. Close the cover and secure it with the screws.

ATTENTION

A safety isolator / disconnect switch should be installed on the mains electricity side of all motor drives.

OPERATING INSTRUCTIONS

ATTENTION


Make sure the connections are correct before you power the unit.

ATTENTION

Make sure the mains supply voltage is within the admissible rated maximum current of the product.

1. Plug the ECH into the mains electricity network.
2. Select the requested temperature via the left rotary switch (**Fig. 4**).

Fig. 4 Temperature setpoint selection




3. Select the operating mode by turning the control switch / knob on the right to the relevant position.

3.1 Manual mode

In manual mode, the fan speed can be selected manually via the switch (position 1 - 5) (**Fig. 5**). In heating mode, the motor will be enabled at the selected speed if the measured temperature is lower than the set temperature. Once the measured temperature exceeds the set temperature, the motor will be disabled. In cooling mode, the motor will be enabled as long as the measured temperature is higher than the set temperature. The unregulated output is activated (230 VAC) while the motor is enabled.


Fig. 5 Manual mode



3.2 Automatic mode

When Auto mode has been selected (**Fig. 6**), the controller automatically adjusts fan speed based on the difference between the setpoint temperature and the ambient temperature. The higher the difference, the higher the fan speed.

Fig. 6 Automatic mode



3.3 Remote mode

Remote mode turns off all user interfaces except Modbus RTU communication. After the remote mode is selected (holding register 20), LED, analogue and unregulated output states are controlled by a Modbus master device via holding registers 21-24.

If the Modbus safety timeout register (Holding register 8) is not 0, it means the Modbus safety timeout is set. Therefore, when the time runs out due to no Modbus communication, the analogue output value will be "position 1" value (holding register 12). After Modbus communication is recovered, the analogue output value will follow again the sensor settings.

VERIFICATION OF INSTALLATION

ATTENTION

Use only tools and equipment with non-conducting handles when working on electrical devices.

Safe operation depends on proper installation. Before start up, ensure the following:

- The mains supply is connected correctly.
- The speed regulator must be properly earth protected.
- During operation, the unit must be closed.
- Protection is provided against electrical shocks.
- The cables are the appropriate size and fuse-protected.
- There is sufficient air flow around the unit.

Verification of operation:

- Switch ON the mains supply.
- Set the temperature to the minimum position (5 °C).
- The connected fan must stop – (if the ambient temperature is higher than the selected setpoint value).
- The valve/heater must be closed.
- Set the temperature setpoint to the maximum position (35 °C).
- The connected fans must run at max speed (6 VDC) – (if the measured temperature is below the setpoint value).
- The valve/heater must be open (230 VAC).

If the unit does not work according to the instructions, the wiring connections and settings need to be checked.

ATTENTION

Applying overvoltage to any of the logical controller parts will cause improper operation or failure to the internal circuit.

 **ATTENTION**

Disconnect and confirm that there is no live current flowing to the unit before servicing.

 **ATTENTION**

Avoid exposing the controller to direct sunlight!

TRANSPORT AND STORAGE

Avoid shocks and extreme conditions; stock in original packing.

WARRANTY AND RESTRICTIONS

Two years from the delivery date against defects in manufacturing. Any modifications or alterations to the product after the date of publication relieve the manufacturer of any responsibilities. The manufacturer bears no responsibility for any misprints or mistakes in this data.

MAINTENANCE

In normal conditions this product is maintenance-free. If soiled, clean with a dry or damp cloth. In case of heavy pollution, clean with a non-aggressive product. In these circumstances the unit should be disconnected from the supply. Pay attention that no fluids enter the unit. Only reconnect it to the supply when it is completely dry.