RXT | ROOM TEMPERATURE TRANSMITTER/SWITCH

Mounting and operating instructions






Table of contents

SAFETY AND PRECAUTIONS	3
PRODUCT DESCRIPTION	4
ARTICLE CODES	4
INTENDED AREA OF USE	4
	4
STANDARDS	4
OPERATIONAL DIAGRAMS	5
WIRING AND CONNECTIONS	5
MOUNTING & OPERATING INSTRUCTIONS IN STEPS	6
MODBUS REGISTER MAPS	9
VERIFICATION OF INSTALLATION INSTRUCTIONS	10
TRANSPORT AND STORAGE	10
WARRANTY AND RESTRICTIONS	10
MAINTENANCE	10



SAFETY AND PRECAUTIONS





PRODUCT DESCRIPTION

The RXT is a combined room temperature transmitter / switch. It provides four pre-defined ranges, one user-definable range, Modbus RTU (RS485) communication, an analog output and a relay output.

ARTICLE CODES

Code	Supply	Connection
RXT-G	15—24 VAC ±10 % 18—34 VDC	3 - wire
RXT-F	18—34 VDC	4 - wire

INTENDED AREA OF USE

- Temperature control in HVAC applications
- For indoor use only

TECHNICAL DATA

- Analog output: 0–10 VDC/ 0–20 mA
- Relay output: C/O (230 VAC/ 2 A)
- Power consumption:
- ▶ no load: max. 25 mA
- ▶ full load: max. 45 mA
- Load resistance:
 - ▶ 0—10 VDC mode > 500 Ω
 - 0-20 mA mode < 500 Ω</p>
- Selectable temperature ranges: 0-30 °C/ 10-40 °C/ 20 50 °C/ 0-50 °C
- Free selectable temperature range via Modbus: 0–50 °C
- Selectable switching point: 0–50 °C
- Selectable hysteresis: 1/2/3/4 °C (and 5 °C only via Modbus)
- Enclosure:
 - rear lid: plastic ABS, black (RAL9004)
 - front cover: ASA, ivory (RAL9010)
- Protection standard: IP30 (according to EN 60529)
- Operating ambient conditions:
 - ▶ temperature: 0—50 °C
- rel. humidity: < 95 % rH (non-condensing)</p>
- Storage temperature: -40—50 °C


STANDARDS

- Low Voltage Directive 2014/35/EU
- EMC Directive 2014/30/EU
- RoHs Directive 2011/65/EU

CE



OPERATIONAL DIAGRAMS



WIRING AND CONNECTIONS

Vin	Positive DC voltage / AC ~
GND	Ground / AC ~
А	Modbus RTU (RS485) signal A
/B	Modbus RTU (RS485) signal /B
Ao1	Analog output (0—10 VDC / 0—20 mA)
GND	Ground
NO1	Normally open contact
COM1	Common contact
NC1	Normally closed contact
Connections	Cable cross section: max. 1,5 mm ²




MOUNTING & OPERATING INSTRUCTIONS IN STEPS


Before you start mounting the RXT transmitter / switch, read carefully "Safety and Precautions". Choose a smooth surface for an installation location (a wall, panel and etc.).

Follow these steps:

- 1. Open the white cover by releasing the locking plates on both sides of the cover and remove it. (See **Fig. 1** *Locking plates release*.)
- **2.** Insert the cables through the cable opening of the enclosure rear lid. (See **Fig. 2** *Mounting dimensions.*)
- **3.** Fix the unit to the wall/panel taking into account that the unit has to be installed at a minimum height of 1,5 m and the air flow has to pass through it free. Mind the correct mounting position and unit dimensions. See **Fig. 2** and **Fig. 3**.




 Do the wiring according to the wiring diagram (see Fig. 4) using the legend information from section "Wiring and connections".








 Check if your unit starts or terminates the network (see Example 1 and Example 2). If it does not, set the NBT jumper to OFF position. (See Fig. 5).






If an AC power supply is used with any of the units in a Modbus network, the GND terminal should NOT BE CONNECTED to other units on the network or via the CNVT-USB-RS485 converter. This may cause permanent damage to the communication semiconductors and/or the computer!

- 6. Customise the standalone settings to the desired ones (if necessary).
 - **6.1** To select the analog output mode, use jumper JP4. The factory setting is 0–10 VDC mode. (See **Fig. 6** *Analog output selection jumper*.)
 - **6.2** To select the sensor range, use jumper JP2. The factory preset is 0–30 °C (See **Fig. 7** and the enclosed information.)





- **6.3** To reset the Modbus settings, put and hold jumper P1 for 20 seconds. (See **Fig. 8** *Modbus reset jumper*.)
- **6.4** To select a hysteresis value, use jumpers JP3 and JP5. The factory preset is 4 °C. (See **Fig. 9** and the jumper combinations.)
- **6.5** To select the setpoint, use trimmer VR1 (**Fig.10**). The factory preset the middle of the range.



- 7. Close the enclosure and fix the cover.
- 8. Switch on the power supply.



Do not exceed the maximum power supply rating! Measure before installation! Unregulated 24 VAC supply units provide higher nominal output voltage and activate the integrated fuse protection.

If a G-type article is using the same AC power supply source (transformer) as F-type article, a SHORT CIRCUIT may result when the power supply and analog signal terminals are connected to the same common ground! In this case always connect different article types to separate AC transformers or use the same article version.

9. Customise the factory settings to the desired ones, through 3SModbus software (if necessary). For the default factory setting see **Table** *Modbus register maps*.



MODBUS REGISTER MAPS

.


	JT REGISTERS	_				_		
		Data type	Description			Data	Values	
1	Temperature level	signed int.	Actual temperature level				250 =	25,0 0
2-10			Reserved, returns 0				0 -	
11	Analog output value	signed int.	Value of the analog output			0—1.000	0 = 1.000 =	0 100
12	Relay status	signed int.	Relay status. When it is On , the contact between COM1 and	NO1 is closed.		0—1	0 = 1 =	C
13	Temperature range	signed int.	Temperature working range selected by jumper or a holding register					0-30 0 10-40 0 20-50 0 0-50 0 Custo
14	Setpoint	signed int.	Setpoint selected by trimmer or a holding register			0-500	250 =	25,0 9
15	Hysteresis	signed int.	Hysteresis for the relay switching selected by jumpers or a holding register				1 = 2 = 3 = 4 = 5 =	1 0 2 0 3 0 4 0 5 0
16	Setpoint out of range	signed int.	Flag that shows if the temperature setpoint is out of the w	Flag that shows if the temperature setpoint is out of the working range				N Ye
17-20			Reserved, returns 0					
ноц	DING REGISTERS	·						
HOL		Data type	Description	Data	Default	Values		
1	Device slave address	unsigned int.	Modbus device address	1-247	1			
2	Modbus baud rate	unsigned int.	Modbus communication baud rate	1-4	2	1 = 2 = 3 = 4 =	=	9.60 19.20 38.40 57.60
3	Modbus parity	unsigned int.	Parity check mode	0-2	1	0 = 1 = 2 =	=	8N 8E 8C
4	Device type	unsigned int.	Device type (Read only)	RXT-X = 1012				
5	HW version	unsigned int.	Hardware version of the device (Read only)	xxxx		0 x 0110 =	= HW	version 1
6	FW version	unsigned int.	Firmware version of the device (Read only)	XXXX		0 x 0130 =	FW	version 1
7	Operating mode	unsigned int.	Enables Modbus control and disables the jumpers an trimmers	d 0-1	0	0 = 1 =	= Standa = Mo	alone mo dbus mo
8	Output overwrite	unsigned int.	Enables the direct control over the outputs. Alwa settable. Active only if holding register 7 is set to 1.	<i>vs</i> 0—1	0	0 = 1 =		Disabl Enabl
9-10			Reserved, returns 0					
11	Temperature range	signed int.	Selects the temperature working range. <i>Always settab</i> Active only if holding register 7 is set to 1.	e. 1—5	1	1 = 2 = 3 = 4 = 5 =	= = =	0-30 10-40 20-50 0-50 Custo
12	Minimum custom temperature range	signed int.	Minimum value of the custom temperature range. Alwa settable. Active only if holding register 7 is set to 1 al register 11 is set to 5.		0	100 =	=	10,0
13	Maximum custom temperature range	signed int.	Maximum value of the custom temperature rang Always settable. Active only if holding register 7 is set 1 and register 11 is set to 5.		500	500 =	=	50,0
14	Setpoint	signed int.	Selects setpoint for the relay switching. Always settab Active only if holding register 7 is set to 1.	e. 0—500	250	250 =	-	25,0
15	Hysteresis	signed int.	Selects the hysteresis for the relay switching. Alwa settable. Active only if holding register 7 is set to 1.	^{/s} 1–5	4	1 = 2 = 3 = 4 = 5 =	= = =	1 2 3 4 5
16-20			Reserved, returns 0			_		
21	Analog output overwrite value	signed int.	Overwrite value for the analog output. Always settable Active only if holding registers 7 and 8 are set to 1.	e. 0—1.000	0	0 = 1.000 =		0 100
		-1		1		1		



VERIFICATION OF INSTALLATION INSTRUCTIONS

Check the status of the blue ON/OFF LED after you switch on the power supply. (See **Fig. 11**.) The ON/OFF LED should blink during the initialization period (30 s) at equal intervals. Then it should give out continuous blue light. If this is not the case, check the connections again.

Check if both LEDs (LEDTX and LEDRX) blink after you switch on your unit. (See **Fig. 12** *Communication detection indication*.) If they do, your unit has detected Modbus network. If they do not, check the connections again.





The status of both LEDs (LEDTX and LEDRX) can be checked only when the unit is energised. Take the relevant safety measures!

TRANSPORT AND STORAGE

Avoid shocks and extreme conditions; stock in original packing.

WARRANTY AND RESTRICTIONS

Two years from the delivery date against defects in manufacturing. Any modifications or alterations to the product after the date of publication relieve the manufacturer of any responsibilities. The manufacturer bears no responsibility for any misprints or mistakes in this data.

MAINTENANCE

In normal conditions this product is maintenance-free. If soiled, clean with a dry or damp cloth. In case of heavy pollution, clean with a non-aggressive product. In these circumstances the unit should be disconnected from the supply. Pay attention that no fluids enter the unit. Only reconnect it to the supply when it is completely dry.