



△ Consult the fan manufacturer for the correct wiring.

First connect the products, then download the firmware for this solution ID via SenteraWeb. The firmware will be automatically downloaded in the connected device(s).

That connect the products, then download the himware for this solution is via centerawes. The himware will be automatically downloaded in the connected device(s).						
Sentera products External products			Parameters settings			
Article codes	Description	EC fan with 0-10 Volt control input	Article codes	Parameters	Values	Descriptions
ECH-8-DM SEPS8-24-40 SIGWM FLTSN-P500-040 ADPT-3RJ-TB	Ambient temperature is measured. The higher the difference between the measured temperature value and the temperature setpoint, the higher the EC fan speed. The unregulated output controls a water valve or an electric heating element. This controller requires a separate Wi-Fi gateway to download the required firmware.	Hot water valve (solenoid 230 VAC)				