

# FCC08-R Intelligent CO/NO<sub>2</sub> sensor

The FCC08-R series are intelligent sensors featuring adjustable temperature, relative humidity and CO/NO<sub>2</sub> ranges. The used algorithm controls a single analogue / modulating output based on the measured T, rH and CO/NO<sub>2</sub> values, which can be used to directly control an EC fan, an AC fan speed controller or an actuator powered damper. All parameters are accessible via Modbus RTU.

### **Key features**

• Universal input voltage: 85-264 VAC / 50-60 Hz

•

•

 $\bullet$  Selectable temperature, relative humidity and CO /  $\mathrm{NO}_{\mathrm{2}}$  ranges

- Silicon based sensor elements for measuring  $\mathrm{CO/NO_2}$
- Fan speed control based on T, rH and  $\mathrm{CO/NO_2}$
- Inset or surface mounting
- Bootloader for updating the firmware via Modbus RTU communication
- $\bullet$  Ambient light sensor with adjustable 'active' and 'standby' level
- Replaceable CO /  $NO_2$  sensor element
- Modbus RTU communication

A o

٧

Т

Ρ

- 3 LEDs with adjustable light intensity for status indication
- Long-term stability and accuracy

	Tech	nical specifications			
Analogue / modulating output	$0-10$ VDC mode: $R_L \ge 50 \text{ k}\Omega$				
	$0-20$ mA mode: $R_L \le 500 \Omega$				
	PWM (open-collector type) mode: $R_L \ge 50 k\Omega$ , PWM voltage level: 3,3 VDC or 12 VDC				
Warm-up time	1 hour				
	Temperature range	0—50 °C			
Typical range of use	Relative humidity range	0-95 % rH (non-condensing)			
Typical range of use	CO range	0-1.000 ppm			
	NO <sub>2</sub> range	0—10 ppm			
Accuracy	± 0,4 °C (range 0-50 °C)				
		± 3% rH (range 0—100 %)			
Protection standard		IP30 (according to EN 60529)			

		Article codes
Article code	Supply	Imax
FCC08-R	85—264 VAC / 50—60 Hz	33 mA

### Area of use

- Demand controlled ventilation based on temperature, relative humidity and CO /  $\mathrm{NO_2}$  - For indoor use only

	Wiring and connections
L	Power supply, line (85-264 VAC / 50-60 Hz)
N	Power supply, neutral
Ao	Analogue / modulating output (0-10 VDC / 0-20 mA / PWM)
GND	Ground AO
Α	Modbus RTU (RS485), signal A
/B	Modbus RTU (RS485), signal /B
Connections	Spring contact terminal block, cable cross section: 2,5 mm <sup>2</sup> ; pitch 5 mm; shielded cable



### Indications




1 - Red LED	On	Measured temperature, relative humidity or CO / $$\rm NO_2$ values are out of range	
	Blinking	Communication with one of the sensors fails	
2 - Yellow LED	On	Measured temperature, relative humidity or CO / $$\rm NO_2$ values are in the alert range	
2 - Tellow LED	Blinking	Modbus communication has stopped and HR8 is activated (Modbus timeout >0)	
3 - Green LED	On	Measured temperature, relative humidity or CO / $$\rm NO_2$ values are within range	
	Blinking	Sensor warming up	
4 - Ambient light sensor	0	Low light intensity / Active / Standby	
5 - CO / NO <sub>2</sub> sensor element	Replaceable in case of faulty operation		
6 - PROG header, P1		Put a jumper onto pins 1 and 2 and wait for at least 5 seconds to reset the Modbus communication parameters	
neadel, PI	1 2 3 4 5	Put a jumper onto pins 3 and 4 and restart the power supply to enter bootloader mode	

**Note:** By default, the LED indicators visualise the measured CO level. When the sensor is in bootloader mode, the green and yellow LEDs flash alternately. During the firmware download, the red LED is flashing additionally.




# FCCO8-R Intelligent CO/NO<sub>2</sub> sensor



\*CO and NO, measurements will return 0 ppm during warm-up time.

•

**Note:** The output changes automatically depending on the highest of the T, rH or CO /  $NO_2$  values, i.e. the highest of the three output values controls the output. See the green line in the operational diagram above. One or multiple sensors can be deactivated. E.g. it is also possible to control the output based on the measured CO value only. It is not possible to control the output based on the measured CO and  $NO_2$  levels simultaneously.



### Stan<u>dards</u>

-	-
C	E
_	-

- Low Voltage Directive 2014/35/EU
  EN 60529:1991 Degrees of protection provided by enclosures (IP Code) Amendment AC:1993 to EN 60529
   EN 60730-1:2011 Automatic electrical controls for household and similar use -
  - Part 1: General requirements
- EMC directive 2014/30/EU:
- -EN 60730-1:2011 Automatic electrical controls for household and similar use -Part 1: General requirements
- -EN 61000-6-1:2007 Electromagnetic compatibility (EMC) Part 6-1: Generic standards Immunity for residential, commercial and light-industrial environments
  -EN 61000-6-3:2007 Electromagnetic compatibility (EMC) Part 6-3: Generic standards Emission standard for residential, commercial and light-industrial environments. Amendments A1:2011 and AC:2012 to EN 61000-6-3
- -EN 61326-1:2013 Electrical equipment for measurement, control and laboratory use - EMC requirements - Part 1: General requirements -EN 61326-2-3:2013 Electrical equipment for measurement
- EN 61326-2-3:2013 Electrical equipment for measurement, control and laboratory use EMC requirements Part 2-3: Particular requirements. Test configuration, operational conditions and performance criteria for transducers with integrated or remote signal conditioning
- WEEE 2012/19/EU
- RoHs Directive 2011/65/EU



#### Modbus registers

The Sensistant Modbus configurator allows you to easily monitor and/or configure Modbus parameters.

The parameters of the unit can be monitored / configured through the 3SModbus software platform. You can download it from the following link:

https://www.sentera.eu/en/3SMCenter

For more information about the Modbus registers, please refer to the product Modbus Register Map.

## 

#### Packaging



Article	Packaging	Length [mm]	Width [mm]	Height [mm]	Net weight	Gross weight
	Unit (1 pc.)	95	85	70	0,2 kg	0,21 kg
FCCO8-R	Carton (10 pcs.)	492	182	84	2 kg	2,3 kg
	Box (60 pcs.)	590	380	280	12 kg	14,2 kg

	Global trade item numbers (GTIN)
Packaging	FCC08-R
Unit	05401003006177
Carton	05401003300701
Box	05401003501115